



PLASMA SERIES

40cm Plasma Island Hood
RH-D3154



reddot winner 2021



WM: RM 4,700 EM: RM 4,935

plasmafresh™

PLASMA AIR PURIFICATION TECHNOLOGY



RECIRCULATION
ONLY

RH-D3154-BKR (Black)
RH-D3154-BLR (Blue)
RH-D3154-ORR (Orange)

Suction Power 650m³/h

Dimension W 410mm D 410mm H 590-2490mm



Plasma Air Purification Technology



LED Touch Sensor Control



Remote Control



Decorative LED Light



3 Speed Settings



Booster Function



Delay Timer



Recirculation




Activated Carbon Filter



Clean & Fresh

LEAVES YOUR KITCHEN FRESH & CLEAN






Sensor Touch Control

Touch control is extremely easy to use and indicates speed, light and delay timer.




Metal Grease Filter

An essential component that filters out grease, smoke, and other airborne particles generated during cooking. This filter with magnet is easy to take apart and clean.



Delay Timer

The cooker hood will switch off automatically at a preset time, so you can proceed with your meal after cooking is done. Meanwhile, the cooker hood will continue to extract the oily fumes, leaving a clean kitchen without smoke or pungent smells.



Remote Control

The remote control allows for easy operation and adjustment of the hood's settings from a distance, eliminating the need to reach or approach the appliance.

PLASMA AIR PURIFICATION TECHNOLOGY

Cleaner air in the kitchen


Developed from state-of-the-art R&D, Plasma air purification technology eliminates 98% of odours, fumes, allergens and pollutants, ensuring your kitchen always stays clean and fresh.

Intelligent Purification: How it works

Plasma purification is a process that changes the molecule composition by harnessing the power of electricity. Comes with a CPU, our Plasma filter efficiently uses a minute and safe amount of electricity to generate a voltage field that electrically charges the molecules of pollutants.

Maintenance - Free

Thanks to the plasma filter, the cooker hood doesn't require frequent cleaning. Making it hassle-free.



Clean and Fresh Function

How to Use?

1. Press and hold the delay timer icon for approximately 3 seconds.
2. Press the ON/OFF switch icon to start the Clean and Fresh function.
3. The timer orange ring icon will light up.
4. Clean and Fresh function is activated to run 6 mins each hour for 24 hours at speed 1.